

SOL/AC/EOL connectors



ANDEL's tried and tested Floodline multizone leak detection systems are well known for being the most reliable, effective and easy to use. The "Plug & Play Auto-Connect" system allows instant, fool-proof connection for quick, no-hassle installation by any engineer, contractor or competent person.

Using a special version of the industry standard "RJ" type network connector, Floodline Plug & Play has universal acceptance. This robust, stable plug and socket system gives quick, easy, positive connection every time. Maintenance, replacement and modification couldn't be easier

8 Zone Detection Cable and patchleader cables are available in a range of standard pre terminated lengths. Other non-standard lengths can be supplied at no extra surcharge. All cables can also be cut and connected on site by trained engineers.

Standard lengths

5m, 7.5m, 10m, 15m

Couplers

In/out couplers perform all connection and zone change functions.

No setup or links to change.

No wire stripping.

No confusion.

OSOL - Start of Line

Connects Leader Cable to Detection Cable

Autocoupler

Connects one detection cable zone to another. In-built system logic automatically sets its relative position and zone address.

O EOL - End of Line

Terminates last zone in line